

KitchenAid DOOR AND PANEL PARTS

UNDERCOUNTER DISHWASHER




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS




Illus No.	. Part No.	DESCRIPTION
1	W10084166 W10084167 W10084168	Console Assembly (Includes Insert) Black White Stainless
2	8531877	Cable, Ribbon
3	8546546	,
4	W10134019	Switch, Door
5	8531873	Board, Interconnect
6	661663	BI-Metal
7	W10077360	Latch Assembly
8	3369051	Screw
9	W10084141	Control, Electronic

DOOR AND LATCH PARTS




Illus No.	. Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus No.		DESCRIPTION
1	3369051	Screw, Door	6	8269259	Gasket, Vent	11	W10078202	Wiring Harness
2	8281217	Screw	7	W10077877	Deflector, Vent	12	8281154	
3	W10056249	Inner Door			(Also Order	13	8535660	Seal,
		Mastic Assembly			ltem 6)			Console/door
		(Also Order	8	W10077882	Dispenser,	14	8535637	Bracket,
		ltem 6)			Assembly			Dispenser
4	W10077883	Inlet, Áir	9	W10077881	Knob, Rinse Aid	15	8531865	Shield,
5	8572611	Vent Assembly	10	8545608	Harness, Vent			Dispenser
		(Also Order			Motor			•
		Item 6)						

FILL, DRAIN AND OVERFILL PARTS




TUB AND FRAME PARTS



TUB AND FRAME PARTS

Illus No.	. Part No.	DESCRIPTION
1 2	W10056238 8574123	Tub Assembly Barrier, Moisture Undercounter
3	W10112096	Door Seal
4	W10082838	Plug Tub
5	3378128	Washer,
		Pronged Cup
6	8572661	Actuator, Assembly
7	8269110	•
8	8573061	
9	8270021	Mount, Door
		Balance
10	3367670	
11	8269145	Bracket, Undercounter
12	3400074	
13	3400074	
14	3370389	
15	8268977	Wheel Leg
16	8524584	
17	8524474	Wheel, Door
• •	0021111	Balance
18	8270020	Spring, Door
		Balance
19	W10082769	Motor, Wax
20	3400892	Screw
21	8268991	Cover, Terminal
		Box
22	8545574	
23	8535568	Link, Door
0.4	0000500	Balance
24	8268582	Insulator, Sound
25	304666	
26	3400014	Screw
27	8573239	Shield, Sound Tub
28	9742648	Bracket,
20	3172040	Thermostat
29	661566	Thermostat
30	W10077370	Strike, Latch
	_	•


PUMP AND MOTOR PARTS



PUMP AND MOTOR PARTS


Illus No.		DESCRIPTION
1	8534952 8283527	Accumulator Assy Shield, Motor
2 3 4	3400069	Screw
	8572618	Sump With Seal
5	8268375	Check Valve, Sump
6	W10083957	Chopper Assembly
7	9741232	Screw
8 9	8531857 8535760	Protector, Inlet
10	3400217	Motor Assembly Screw
11	W10084567	Screen, Separation
12	W10084107	Sump & Motor
		Assembly
		(Includes
40	0000504	Item 13)
13 14	8269524 8533949	Tab, Sump Nut
15	661662	Pump, Drain
16	8531019	Volute, Back
.0	0001010	(Also Order
		Items 21 & 26)
17	8269144	Hose, Drain
18	8535759	Motor
19	8268397	Seal, Volute
20 21	8531017 8268403	Impeller Kit
۷1	0200403	Face Seal Assembly (Also Order
		Item 26)
22	356138	Clamp, Hose
23	W10134016	Optical Water
		Indicator
24	8535474	Capacitor
25	8534946	Shield,
26	8531018	Capacitor Washer

UPPER WASH AND RINSE PARTS



HEATER PARTS


For Models: KUDU03STBL3, KUDU03STWH3, KUDU03STSS3 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8537057	Heater Element Assembly (Also Includes Item 2)
2	717273	Washer, Heater Element
3	8268548	Nut, Heater Element
4	3400931	Retainer, Spring Grip

NOTE: If heater element is removed, it must be replaced.

UPPER RACK AND TRACK PARTS




UPPER RACK AND TRACK PARTS For Models: KUDU03STBL3, KUDU03STWH3, KUDU03STSS3 (Black) (White) (Stainless)

Illus No.	. Part No.	DESCRIPTION
1 2 3	8561731 W10082839	Dishrack, Upper Housing, Adjuster Actuator, Adjuster
4 5	W10077838 W10077839 8268653 8270138	Right Hand Left Hand Adjuster Assembly Wheel
6 7	8268703 8281156	Axel, Adjuster Screw
8 9	8562030 W10082853	Tine Row Clip, Pivot
10 11	8539103 8539149	Positioner, Multi Insert, Fold Down Tines
12 13	8539102 8539148	Positioner, Dual Clip, Insert Tines
14 15	W10082840 9741232	Cover, Adjuster Retainer
16 17	W10082834 W10077844	Positioner, Arm Clip, No-Flip
18	W10077852 W10077851	Track, Assembly Right Hand Left Hand
19	W10077876	(Also Order Item 21) Mount, Track (Also Order Item 21)
20	W10077848	Stop, Track Right
21	W10077847 9743002	Left Gasket, Bracket Mounting
22 23	3400072 8539110	Screw Handle, Dishrack
24 25	8562029 8562026	Cupshelf Assembly Clip, Cupshelf

LOWER RACK PARTS


For Models: KUDU03STBL3, KUDU03STWH3, KUDU03STSS3 (Black) (White) (Stainless)



Silverware 8519662 Lid, Basket Center


W10086370 Insert, Single W10086340 Insert, Double 8519702 Basket, Utensil 8519716 Basket–Small Items

THIRD LEVEL RACK AND TRACK PARTS



IIIus.	. Part	
No.	No.	DESCRIPTION
1		Track
'	W10077855	
	W10077856	
2	W10077854	Stop, Track
3	8564899	Mount, Track
4	8564900	Rack Assembly
		(Third Level)
5	8564901	Basket- TLR

LOWER WASHARM AND STRAINER PARTS



ıus	. Part	
No.	No.	DESCRIPTION
1	W10077965	Wash Arm Assembly
2	W10077899	
		Rear Feed
		(Also Order
		Item 3)
3	8268340	Seal, Sprayarm
4	W10077898	Hub, Lower
		Sprayarm
		(Also Order
		Item 3)

OPTIONAL PARTS (NOT INCLUDED)

For Models: KUDU03STBL3, KUDU03STWH3, KUDU03STSS3 (Black) (White) (Stainless)

Illus. **Part**

DESCRIPTION No. No.

No. No. **DESCRIPTION**

Part

Illus.

Illus. No. No. **DESCRIPTION**

Part

ACCESSORIES

Side Panel Kits 8171656 White 8171657 Black 8171658 Biscuit 8171659 Stainless Steel

Custom Panel & Trim Kit 8212489 Black

Towel Bar Handle Kit 8573938 Stainless Steel

Drain Hose 3385556 12 Ft.

Vinyl Touch-Up (4 oz.) 676453 White 676455 Grey 4396853 Silver Atlantis

Moisture Barrier Kit 4396277 Kit

PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black 4392899 Biscuit 4396603 Meteorite

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White 285006 Superior Black 4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit

POWER CORD KIT

4317824 Power Cord Kit (Includes Power Cord & Misc. Hardware)

ANTI-TIP KIT

8171477 Floor Mount Kit

DISHRACK REPAIR

4396838 White 4396840 Grev 4396854 Silver Atlantis

16

W10101563